

## ISL55180 Quick Start Application Note

Rev A01: 06/22/12



This document contains information on a product under development. The parametric information contains target parameters that are subject to change.

## Document Revision History

Revision	Date	Description
A01	6/22/12	Initial Draft

## Table of Contents

1	Introduction .....	3
1.1	Set ISL55180 Supplies .....	3
1.1.1	Measure REXT .....	3
1.2	Register/RAM Access (CPU Port Transactions) .....	4
1.2.1	Read Die ID Register .....	4
1.2.2	Register Access.....	4
1.2.3	RAM (DC Level Memory) Access.....	5
1.3	Reset State .....	6
1.4	Set a Force Voltage Output on FORCE_0 .....	7
1.5	Measure Junction Temperature.....	8
	Table 1: Power-ON Current Values after Reset.....	3
	Table 2: Die ID Register Values.....	4
	Table 3: Write/Read Registers.....	4
	Table 4: Write/Read RAM (DC Level Memory).....	5
	Table 5: Force Voltage Example.....	7
	Table 6: Voltage Range Selection .....	7
	Table 7: 8V Range DAC Mapping.....	8
	Table 8: 16V Range DAC Mapping.....	8
	Table 9: Measure Junction Temperature .....	8

## 1 Introduction

This document describes the steps to perform an initial system check-out of an ISL55180 device.

These instructions assume the customer system can set the ISL55180 supplies, has a mechanism to read/write registers, has the ability to measure voltages (either using an external DMM or system resource), control the digital input pins, and so on. The customer should also be able to adequately cool the ISL55180.

**Important Note:** The steps described below illustrate a cause and effect to demonstrate how to interface with the device. In a normal application; sequencing, calibration and other factors may require the registers to be written in a different order.

### 1.1 Set ISL55180 Supplies

The first step is to apply the appropriate voltage. After power is applied, it is recommended to toggle the hardware reset (active high) on the ISL55180 device. Ideally all power supplies would become active simultaneously. However, since it is difficult to guarantee simultaneous levels, the following sequence is recommended:

1. VEE
2. VCC
3. VCCO\_#
4. VDD
5. VOH\_SDIO
6. V\_REF

Schottky diodes are also recommended on a once per board basis to protect against any power supply restrictions. This can be reviewed in more detail in the power supply section of the ISL55180 datasheet.

Verify the voltage at the ISL55180 pins or within close proximity to ensure there are no IR drops. In addition, the customer should verify the approximate current flow for each supply. Table 1 below shows some typical current values after a hardware reset has been applied to the part.

**Note:** In some systems, it may not be possible to measure the supply currents on a device by device basis.

**Table 1: Power-ON Current Values after Reset**

Supply	Voltage (V)	Approximate Current (mA)
VCC_OUT	5.0	2.0
VCC	13.0	93.0
VEE	-3.0	92.0
VDD/VOH_SDIO	3.3	61.0
VREF	3.0	0.0

#### 1.1.1 Measure REXT

The next step is to measure the voltage of REXT. REXT voltage should track the VREF voltage within 25mV.

## 1.2 Register/RAM Access (CPU Port Transactions)

The following steps perform simple register/RAM access (write/read) to verify that the CPU port is functioning.

### 1.2.1 Read Die ID Register

Read the Die ID register (address = 0xC0FF); Table 2 lists the expected return values for different silicon revisions.

**Table 2: Die ID Register Values**

Rev	Read-back Data (HEX)
4	0xF164
#	0xF16#

### 1.2.2 Register Access

Follow Table 3 to verify the basic ability to write/read registers. The following bullet items highlight some key aspects of a register access:

- Address bit A15 (Register Bit) must be '1' to access a register
- Address bit A14 (Central Bit) is used to distinguish between Per-Chan and Central Registers
- WE bit must be '1' for the corresponding Data bits to be written
- WE bits should be read back as a don't care (X), however they typically read back '0'.
- Writing to Undefined Data bits has no effect
- Undefined Data bits (typically) read back '0'
- A RESET sets all registers to a default value of '0000' (except Read-Only registers)
- Refer to the CPU Protocol Timing diagram for details.
- Address bits A6-A13 are used to select which channel will be written. The CPU port can write to any or all selected channels with one write transaction by setting the selected channel bit high.

**Table 3: Write/Read Registers**

Description	Address (HEX)	Write Data (HEX)	Read Data (HEX)
Reg Addr#4, Chan#0: Set all bits high	0x8044	0xFFFF	0x7BEF
Reg Addr#4, Chan#0: Clear Kelvin# bits	0x8044	0x8000	0x03EF
Reg Addr#4, Chan#0: Clear rest of bits	0x8044	0x0410	0x0000
Central Addr#2: Set all bits high	0xC002	0x3FFF	0x17B7
Central Addr#2: Clear all bits	0xC002	0x2848	0x0000
Central Reg Addr#0: Software RESET	0xC000	<don't care>	0x0000 (all registers)

### 1.2.3 RAM (DC Level Memory) Access

Follow Table 4 to verify the basic ability to write/read RAM. The following bullet items highlight some key aspects of a RAM access:

- The Read-back Data matches the Written Data
- Address bit A15 (Register Bit) must be '0' to access RAM
- Address bit A14 (Central Bit) must be '0' to access RAM
- A RESET does NOT set the RAM contents to a default value. They are left unchanged
- A RAM read-back requires 2 additional clock cycles more than a register read-back
- Refer to the CPU Protocol Timing diagram for details
- Address bits A6-A13 are used to select which channel will be written. The CPU port can write to any or all selected channels with one write transaction by setting the selected channel bit high.

**Table 4: Write/Read RAM (DC Level Memory)**

Description	Address (HEX)	Write Data (HEX)	Write Data (HEX)
ForceB# Level<15:0>, Chan#1	0x0081	0xFFFF	0xFFFF
ForceB# Offset<15:0>, Chan#1	0x0091	0xAAAA	0xAAAA
ForceB# Gain<15:0>, Chan#1	0x00A1	0x5555	0x5555

### 1.3 Reset State

Whenever a Hardware or Software reset is issued, the device is configured into the following state.

Note: The rest of the examples rely on the default (reset) configuration to demonstrate the minimum register transactions to achieve the desired configuration.

- RAM (DC Level Memory) – Unknown at power ON. Left unchanged if reset issued from a valid configuration while power is still ON.
- Registers – all registers are initialized to '0'; which implies the following (all settings are not listed below):
  - All switches open
  - All DPS channels are in High-Z
  - Feedback = Tight Loopback
  - Sel-FV# = ForceA#<15:0>
  - All current ranges are open
  - Voltage Range = 8V Range
  - FV-Mode = High Current
  - I-Clamps are disabled
  - Monitor and MI\_Monitor are in High-Z
  - CPU-EN = 0: Channel is disabled
  - Kelvin and Current Alarms disabled

## 1.4 Set a Force Voltage Output on FORCE\_0

Use the following sequencing to output a voltage on the ForceA#<15:0> on channel 0. The FORCE\_0 pin and SENSE\_0 pin must be connected external to the ISL55180 if the SENSE feedback option is used. The example only shows register values that must be changed from default values.

Note: The FORCE\_0 “Output Voltage” is an approximate voltage since these are un-calibrated settings.

**Table 5: Force Voltage Example**

Description	Address (HEX)	Data (HEX)	Feed back	FORCE_0 (V)	MONITOR (V)
Software Reset	0xC000	0x0000	Tight	HiZ	HiZ
IR = IR5 (256mA Range)	0x8045	0x1800	Tight	HiZ	HiZ
ForceA0<15:0> Value = 0.5V	0x0040	0x4FFF	Tight	HiZ	HiZ
ForceA0<15:0> Offset = 0V	0x0050	0x7FFF	Tight	HiZ	HiZ
ForceA0<15:0> Gain = 1.0	0x0060	0x7FFF	Tight	HiZ	HiZ
CPU-EN0 = 1	0x8041	0x0009	Tight	0.5V	HiZ
Sel-MU-Pos0<1:0>=1, (FORCE)	0x8045	0x0005	Tight	0.5V	HiZ
Set MUR<1:0>=1 (4V Range) (Gain=0.5V/V Offset=0.5V)	0xC001	0x0280	Tight	0.5V	HiZ
Set CPU-Mon-OE=1	0xC001	0x0050	Tight	0.5V	0.75V
Set FVR0=1 (16V Range) (DAC code doesn't change, but output voltage changes based on new voltage range. For more detail see Note1 below and Voltage Range Selection section of ISL55180 Data Sheet.)	0x8040	0x0600	Tight	3.0V	2.0V
ForceA0<15:0> Value = 2.5V (16V Range)	0x0040	0x47FF	Tight	2.5V	1.75V
Sel-MU-POS0<1:0>=0, MI-S (Measure Current Mode)	0x8045	0x0004	Tight	2.5V	1.25V
Sel-MU-NEG0<1:0>=2, FI-Zero (Measure Current Mode)	0x8045	0x0028	Tight	2.5V	0.5V
Set MUR<1:0>=0, MI Range (Gain=1.33V/V Offset=1.5V)	0xC001	0x0200	Tight	2.5V	1.5V
Add 10 ohm resistor between the FORCE_A0 and GND (250mA)	N/A	N/A	Tight	2.44V	1.9V (244mA)
Tight-Loop*0=1 Take out of tight loopback	0x8040	0x0002	FORCE_#	2.46V	1.91V (246mA)
Sel-V-FB0<1:0>=1 Set Sense Feedback	0x8004	0x0280	SENSE_#	2.5V	1.92V (250mA)

Note 1: Please see Tables 6, 7, and 8 for more details on the Voltage Range DAC mapping.

**Table 6: Voltage Range Selection**

FVR# Bit	Voltage Range (V)
0	8
1	16

**Table 7: 8V Range DAC Mapping**

8V Range	Programmed DC Level (V)
0x0000	-2
0x7FFF	+2
0xFFFF	+6

**Table 8: 16V Range DAC Mapping**

16V Range	Programmed DC Level (V)
0x0000	-2
0x7FFF	+6
0xFFFF	+14

## 1.5 Measure Junction Temperature

The following steps show how to measure and calculate the junction temperature using the internal temperature sensors.

$$T_j = (V_a(T_j) - V_b(T_j)) * 1637 - 221$$

The measured temperature will be dependent on if there is a heat sink and/or air-flow present.

**Table 9: Measure Junction Temperature**

Description	Address (HEX)	Data (HEX)	MONITOR Output (V)
Software Reset	0xC000	<don't care>	Hi-Z
Ch#2: Sel-MU-Pos2<1:0>=3	0x8205	0x00D6	Hi-Z
Ch#2: Sel-MU<2:0>=2	0xC001	0x000A	Hi-Z
Set MUR <1:0>=1 (4V Range) (Gain=0.5V/V Offset=0.5V)	0xC001	0x0280	Hi-Z
Ch#2: Sel-Diag2<3:0>=0xE (Central-Diag-A, Va)	0x8204	0x001E	Hi-Z
Set CPU-Mon-OE=1 Enable Monitor	0xC001	0x0050	Measure Va at monitor pin.
Ch#2: Sel-Diag2<3:0>=0xF (Central-Diag-B, Vb)	0x8204	0x001F	Measure Vb at monitor pin

Example: Using the previous setup:  $V_a = 1.637V$   $V_b = 1.559V$  measured at monitor for the test setup. Since the 4V range was used in the MUR register, the voltages will have to be adjusted according to the gain and offset of the measurement unit range.

- 1) 4V MUR (measurement unit range): gain = 0.5V/V, offset = 0.5V
- 2) Solve for  $V_x T_j$  voltage using the following equation:  $V_x = (\text{gain} * V_x T_j) + \text{offset}$   
 $V_x$ =measured value at monitor (scaled by measurement unit)  
 $V_x T_j$ =actual input to measurement unit.
- 3) Rearrange above equation to the following:  $V_x T_j = (V_x - \text{offset})/\text{gain}$   
This will find actual  $V_a T_j$  and  $V_b T_j$  voltages.
- 4)  $V_a T_j = 2.274 = (V_a - \text{offset}) / \text{gain} = (1.637V - 0.5V)/0.5$
- 5)  $V_b T_j = 2.118 = (V_b - \text{offset}) / \text{gain} = (1.559V - 0.5V)/0.5$
- 6)  $T_j = 34C = (V_a(T_j) - V_b(T_j)) * 1637 - 221$



